## **RAY-BAR ENGINEERING CORPORATION**

TECHNICAL DATA FOR 1" WIRELITE NT INSULATED GLASS UNIT


FIRE RATED SIZES IN MAXIMUM VISIBLE EXPOSED AREA "DAYLIGHT" VIEW LIMITS





Product Trade Name: WIRELITE NT IGU [ UL]




It is the responsibility of the customer to verify and confirm fire rating requirement prior to ordering.









## 1/4" WIRELITE NT WHEN GLAZED WITH PEMKO FG3000 FIRE TAPE









- UL Listed/Classified and permanently labeled, with required hosestream test.
- Standard stock sizes available up to 48" x 96", and filmed for safety impact resistance.
- WireLite-NT Fire rated safety glass is permanently labeled meeting ANSI Z97.1 and CPSC 16 CFR 1201 Cat II requirements for impact resistance. Safety Glass is required in door vision lites and windows that occur within 24" of a door opening or within 36" of floor. Safety Glass is NOT tempered, impact-proof, shatter proof or scratch resistant.
- Standard wire glass pattern is Diamond.
- Available in IGU for Low-E, Tinted, Reflective, 1-Way Mirror and X-Ray Protective.
- UL File R38927, Testing to UL 9, UL 10C, NFPA 252 and NFPA 257.

## MAXIMUM SHEET SIZE OF WIRELITE NT IS 48"X96"

- For more size options or higher fire ratings utilize FireLite Ceramic Glass Products.
- For Fire Resistive, Radiant and Conductive Heat Barrier utilize PILKINGTON PYROSTOP®Glass (Meeting ASTM E-119 and UL 263).

RAY-BAR ENGINEERING CORPORATION WWW.RAYBAR.COM

LIFE AND SAFETY PRODUCTS



RADIATION
 FIRE
 BALLISTICS
 BLAST

PH: (800) 444-9729 E-MAIL: SALES@RAYBAR.COM FAX: (800) 333-9729
"WHEN PROTECTION IN REQUIRED. THERE IS NO SUBSTITUTE FOR SKILL AND EXPERIENCE"

© 2019 Ray-Bar Engineering Corporation. \* Ray-Bar is a registered trademark of Ray-Bar Engineering Corp. \*FireLite and FireLite Plus are registered trademarks of NEG Co, Ltd.
\* Pilkington Pyrostop is a registered trademark of Pilkington plc. \* WireLite and Fireglass are registered trademarks of TGP. \* For additional information and details please contact Ray-Bar.